



PARTS LIST

No.	Parts No.	Description	Q'ty
1	IW1040-01	Ball Bearing	2
2	IW1040-02	Front End Plate	1
3	IW1040-03	Rotor	1
4	IW1040-04	Rotor Blade	6
5	IW1040-05	Rolled Pin	1
6	IW1040-06	Cylinder	1
7	IW1040-07	Rear End Plate	1
8	IW1040-08	Rear Gasket	1
9	IW1040-09	End Cap	1
10	IW1040-10	Hex.Soc.Hd.Bolt	4
11	IW1040-11	Hammer Cage	1
12	IW1040-12	Hammer Dog	1
13	IW1040-13	Hammer Pin	2
14	IW1040-14	Anvil	1
15	IW1040-15	Rolled Pin	1
16	IW1040-16	Motor Housing	1
17	IW1040-17	Throttle Pin	1
18	IW1040-18	O Ring	1
19	IW1040-19	Air Regulator	1
20	IW1040-20	O Ring	1

No.	Parts No.	Description	Q'ty
21	IW1040-21	Reverse Valve	1
22	IW1040-22	O Ring	1
23	IW1040-23	Spring	2
24	IW1040-24	Set Ball	2
25	IW1040-25	Lever Reverse	1
26	IW1040-26	C Ring	1
27	IW1040-27	Rolled Pin	1
28	IW1040-28	Trigger	1
29	IW1040-29	Bushing	1
30	IW1040-30	Steel Ball/Valve Stem	1
31	IW1040-31	Spring	1
32-2	IW1040-32-2	Muffle Plate / Cover	1
33	IW1040-33	O Ring	1
34-3	IW1040-34-3	Hose Fitting (NPT18T)	1
34-4	IW1040-34-4	Hose Fitting (PT-19)	1
35	IW1040-35	Dust Cover	1
36A	IW1040-36A	Muffler	1
37	IW1040-37	Handle Cover (M: Nbr Black)	1
38	IW1040-38	Muffler	1