



PARTS LIST

No.	Parts No.	Description	Q'ty
1	AH603-01	Housing	1
2	AH603-02	Pin (3x25L)	1
3	AH603-03	Protecting Rubber	1
4	AH603-04	Washer (17x28x1.2)	1
5	AH603-05	Air Inlet	1
6	AH603-06	Trigger Set	1
7	AH603-07	Spring (37x3x20L)	1
8	AH603-08	Wear Ring	2
9	AH603-09	O-Ring (AS032)	4
10	AH603-10	Cylinder Sleeve	1
11	AH603-11	Valve Seat	1
12	AH603-12	Valve Pin	2

No.	Parts No.	Description	Q'ty
13	AH603-13	Valve Disc	1
14	AH603-14	Valve Cap	1
15	AH603-15	Piston	1
16	AH603-16R	Cylinder Set -Round	1
	AH603-16H	Cylinder Set -Hex 10mm	1
17	AH603-17	Ball (5/16")	4
18	AH603-18	Rubber Ring	1
19	AH603-19	Clamp Nut	1
20	AH603-20	Cylinder Case	1
21	AH603-21	Spring (30.4x2.3x36L)	1
22	AH603-22	Collar	1
23	AH603-23	Snap Ring (STW-29)	1